






# *gizmead*


gardening essentials  
storage products  
health products  
homewares


## EXTENSION POLE ... How to fit new pole lock onto pole


- 


1. Remove black sleeve (OPEN) from outer tube (POLE).
- 


2. Completely pull out inner tube.
- 


3. Remove pins from inner pole guide and pull out black sleeves.
- 


4. Discard all four plastic parts.
- 

5. Loosen nuts on new pole lock and slide new pole onto inner pole.
- 

6. Replace inner pole guide and pin.
- 

7. Put inner pole back into outer pole.
- 

8. Position new pole locker onto the outer pole, making sure it is completely to the stop.  
(Use hammer to tap on if necessary)
- 

9. Tighten up nut on pole locker to outer pole.
- 

10. Adjust nuts on lock lever to your requirements.